


Gigaset S650H PRO DECT Handset

Handset Quick Start Guide v1 07/02/2019



1	Display screen
2	Status bar
3	Volume keys
4	Display soft keys
5	End call key, on/off key
6	Message key
7	Profile key
8	Hash key
9	USB socket
10	Microphone
11	Star key
12	Headset connection (2.5mm jack)
13	Key 1
14	Recall key
15	Talk key/ Handsfree key
16	Control key, menu key

Installing Your DECT Phone

When you open the box for your device you will find the following items:

- The main handset chassis
- Rechargeable battery
- Handset battery cover
- Charging cradle
- UK PSU with attachment for the charging cradle
- Belt clip

You will first need to insert the rechargeable battery into the handset.



▶ Insert the batteries (for correct +/- direction, see diagram).

▶ Fit the battery cover from the top.
▶ Press the cover until it clicks into place.

To re-open the battery cover:
▶ Insert a fingernail behind the notch at the top of the cover and slide it downwards.

To use the S650 handset with Inclarity it must be registered to a Gigaset base station which has Inclarity service. The handset will not work without a) registering with a base station, and b) access to an Inclarity Subscriber Extension.

To register with a N300IP or N510IP base station you should select via the screen of the handset **Menu -> Settings -> Registration -> Register Handset**. Then simultaneously on the base station you should press and hold down the large blue button on side of the device. The handset should then report that it has registered.

Using Your DECT Phone

To turn the device on/off

Press and hold the on/off key (5).

To Make a Call

Dial the destination number, press the talk key (15) and wait to be connected.

When you have finished your call press the end call key (5).

NOTE: UK calls should be dialed using the full STD area code. International calls should be dialed beginning '00' and then the country code, followed by the rest of the number.

Device Volume

While on a call press up on the menu key (16) and then press left and right to adjust the handset volume. Alternatively use the Volume keys (3).

Device Mute

While on a call, press right on the menu key (16) to mute the input of your microphone. To unmute press the same button a second time.

Device Handsfree

While on a call press the handsfree key (15). To take the call off handsfree press the same button a second time.

On/Off Hold

Whilst on an active call press the **R** key.

To resume the call select **End** Display key.

Locking/Unlocking the Keypad

While on the home screen press and hold the Hash key (6) to lock the keypad. Press and hold the Hash key (6) again to unlock.

*NOTE: Emergency numbers **cannot** be dialed if the keypad is locked.*

Call Transfer

Whilst on an active call press the **R** key or select the **Ext Call** Display key. Enter the telephone number of the new party and wait for them to pick up. When you are ready to complete the call transfer, press the **R** key a second time.

If you would prefer to blind transfer a call, then simply hang up the new call after it starts ringing, but before the called party picks up.

*NOTE: You can press **End** to cancel the transfer and return to the original caller.*

Phone Manager Portal

Your device will be associated with a phone system Extension that will have some personal call forwarding and voicemail settings that can be controlled via an online web portal called Phone Manager. To log in go to <https://myphone.inclarity.co.uk> and enter your VoIP telephone number and associated password. If you do not know your password, then please contact your IT administrator or phone system supplier. More information on how to use this portal can be found in our **Phone Manager User Guide**.

3-Way Calls (Simple Conferencing)

Whilst on an active call press the **R** key or select the **Ext. Call** Display key. Enter the telephone number of the new party and wait for them to pick up. When you are ready to start the call conference, press the **Conf** Display key.

You can press the **End Conf** Display key to split the call conference back into 2 separate calls.

NOTE: If you choose to hang up on the conference call it will end and the other two parties will be hung up.

Do Not Disturb

There is no DND function on the S650H.

Call Lists & Redial

While the handset is idle, press the **Calls** Display key to review your call history.

To redial the number associated with a previous call, select the call and press the talk key (15).

Contact Directories

While the handset is idle, press down on the menu key (16) to view your local handset directory. Alternatively, you can navigate via **Menu** -> **Contacts** -> **Directory**.

If you are using the S650H on a base station correctly integrated with Inclarity's Broadworks then you will also be able to access the integrated Enterprise Directory. To view this directory navigate to **Menu** -> **Contacts** -> **Online Directory**, or press and hold down on the menu key (16).

NOTE: At this time this integration is only possible on the Gigaset N720IP wide area DECT system.

To dial a contact, select it from the relevant list and then press the talk key (15).

Bluetooth

To activate the Bluetooth feature navigate to **Menu** -> **Additional Features** -> **Bluetooth**.

Select **Activation** and then press the **Change** button underneath so that the box is ticked.

Then navigate down and search for **Search for Headset** to pair your new device.

To use an already paired device instead choose **Known Devices** and select your device from the list.